

# Technische info

Koppelingen keuze  
Couplings choice  
Kupplungen nach Wahl  
Choix de Accouplement

Type	KS	KK	KG	KR7	KM	KA	KC35	KH	KT	KV
CT1-10-3KS	*/**									
CT2	*/**	*/**								
RT1-10				**	*					
ST1-5/10-1AS	**							**	**	
ST1-2AS	**	**								
ST-07	**				**			**	**	
ST-09	**				**			**	**	
ST2-1AS	*							**	**	
ST2-2AS	**	**								**
ST10-1AS								**	**	
ST10-2AS	*	**			**					
T1-20/40/60	**	**								
T10-1AS								**	**	
T10-2AS	**	**								
T20-20	**	**								
T2-80/100/125		**	**							
T3-170			**							
T3-200			**							
TP2-140	*	*/**	**							
TS20-18	**	**								
TS2-32	**	**								
TS30-25		**								
TS30-40		**								
TS3-130			**							
TS3-90			**							
TW2-16/22						**				
W1-12						**	**			
W2-30/40	*/**	**		**						
W3-80/100	*	*/**	**							

Coupling input shaft

Kupplung Antriebswelle

Accouplement de l'arbre d'entrée

Coupling output shaft

Kupplung Abtriebswelle

Accouplement de l'arbre de sortie

Technische Informatie | Technische Daten | Technical data | Données techniques